Polycom Remote Control for both the FX and VS4000 h.323 systems

Place or end a call

Near button: Show a different camera source or full screen of your location.

Far button: Used to show a far-site camera or video source. Also use to full screen the remote location.

Middle Red Button: Pressing this button is like the Enter key on your computer. Used to select a highlighted item on the menu.

Red Arrow buttons: Used to navigate through menus. The right arrow is also used to enter a dot for IP addresses.

Zoom button : Press + to zoom your picture in. Press - to zoom your picture out.

Volume buttons: Used to control the audio that **you** hear from remote sites. Remember that your tv volume also controls this.

Mute button: Pressing it once will mute the sound that you are sending to the far sites. Press it again and you will un-mute.

Menu button : Press to get back to the main menu.