


# The Incoming Amp and Outgoing Mixer - Great Western Network

Incoming Amp is the top Unit. It controls the sound that is coming IN to your room. Master at 10 or 11 O'clock and the individual knobs at 11 or 12:00 as needed to hear. *When in h.323 mode, monitors 1,2,3 should be turned down and knob #4 labeled Codec should be turned up.*



Ourgoing Amp is the bottom Unit. It controls the sound that your room sends OUT to other sites. The Instructor mic does not need to be turned up unless someone is speaking from up at the teacher station. The master should be at 10 or 11 and the Student Mic knob at about 11:00. Turning the Outgoing up to much beyond 11 may cause feedback and/or ringing.