

## Switching to h.323 mode in a combination analog/h.323 classroom

Open the cabinet on the lower right hand corner of the teacher console (below the Incoming and Outgoing audio units). There will be a switch (the number of buttons will vary from 2 to 8) that will be labeled to show that pushing button #1 will put the system in analog mode and the button #2 will put the system in h.323 mode. (#1 is Analog / #2 is Codec) The other 3 boxes are distribution amps that should always be kept on. You will need to turn knob 4 UP on the incoming amp and also make sure that the volume on the Polycom remote control is pushed several times. Knobs 1,2 and 3 on incoming should be turned down.



Analog mode

h.323 mode -  
Polycom

Changing to h.323 mode will make monitor #1 be used as a Polycom unit. Monitors 2 and 3 will remain in Analog mode. When having an h.323 event, keep the volume turned down on monitors 1,2,3 on the Incoming Amp. (See Incoming Amp)